Introduction

The GT-AI-420 transducer is a 2-wire loop-powered 4-20 mA signal isolator with one input/output channel. It will accept one analog current or voltage input signal, isolate it and sink a current output signal. The input has several fixed ranges for various applications.

The device derives it's operating power from the output current loop that is provided by the receiving device and has an on-board transformer that provides complete input/output signal isolation.

Both the input and output are sinking type and the input signal types are easily selected with DIP switches.

The product comes with standard snap-track for easy mounting.

Applications

- Isolated signal conversion
- Eliminate ground loop wiring problems
- Variable frequency motor drive signal isolation
- Electric actuator isolation
- Easily interface recorders, data loggers and controllers
- Interface and isolate DDC, EMS and HVAC panels

Before Installation

Read these instructions carefully before installing and commissioning the GT-AI-420 transducer. Failure to follow these instructions may result in product damage. Do not use in an explosive or hazardous environment, with combustible or flammable gases, as a safety or emergency stop device or in any other application where failure of the product could result in personal injury. Take electrostatic discharge precautions during installation and do not exceed the device ratings.

Mounting

The snap-track device may be mounted in any position. Use only fingers to remove the pcb from the snap-track, do not pry on the pcb with tools. Do not flex the pcb during removal or installation. Slide the pcb out of the snap-track or push against one side of the snap-track and lift the pcb out. Ensure any metallic mounting hardware does not contact the underside of the pcb.

Avoid mounting in areas where the transducer is exposed to vibrations or rapid temperature changes.

Wiring

Deactivate any power supplies until all connections are made to the device to prevent electrical shock or equipment damage. Follow proper electrostatic discharge (ESD) handling procedures when installing the device. Use 22 AWG shielded wiring for all connections and do not locate the device wires in the same conduit with wiring used to supply inductive loads such as motors. Make all connections in accordance with national and local codes.

The analog input signal is connected to the **IN**+ and **IN**terminals and the analog output signal is connected to the **OUT**+ and **OUT**- terminals. The input and output signals are completely isolated from each other.

Study the wiring diagrams for proper connections with various input signal types.


Factory Configuration

The GT-AI-420 I/O is preset for 4-20 mA input / 4-20 mA output. The input signal may be changed by using the DIP switches as shown below.

Calibration

The isolator is factory calibrated to \pm 0.1 % accuracy on the 0-5 Vdc input type. Using any other range will result in a transfer accuracy of $< \pm 1$ %. If a higher accuracy signal is required simply apply the full-scale input signal and adjust the output signal to 20.00 mA using the calibration pot.

Input Signal Type	S1	S 2	S 3
0-5 Vdc	OFF	OFF	OFF
0-10 Vdc	OFF	ON	OFF
1-5 Vdc	OFF	OFF	ON
2-10 Vdc	OFF	ON	ON
0-20 mA	ON	OFF	OFF
4-20 mA	ON	OFF	ON



0-5 Vdc Shown

General Specifications

-	
Power Supply	Powered by output-loop current (15-30 Vdc)
Isolation	1000 Vrms input to output
Accuracy	. ± 0.1 % typical
Operating Conditions	0 to 50 °C (32 to 122 °F), 5 to 95 %RH non-condensing
Storage Conditions	-30 to 70 °C (-22 to 158 °F), 5 to 95 %RH non-condensing
Wiring Connections	Screw terminal block (12 to 24 AWG)
Weight	56 gm (1.98 oz)
Enclosure	Snap track mounting, 2.4" long x 3.25" wide (61 x 83 mm)

Input Signal

Input Voltage Ranges 0-5, 0-10, 1-5 and 2-10 Vdc Input Voltage Impedance > 10 K Ω

Input Current Ranges 0-20 and 4-20 mA Input Current Impedance 250 Ω Current Signal Type Sink (external transducer generates 4-20 mA)

Output Signal

